


QUARTZ MOVEMENTS


3 HAND



SET YOUR TIME

1. Pull out Crown until it clicks into Position 1.
2. Rotate to adjust time.
3. Push back in to set.

3 HAND W/ DATE




SET YOUR DATE/TIME

1. Pull out Crown until it clicks into Position 1.
2. Rotate clockwise to adjust date.
3. Pull out Crown from Position 1 until it clicks into Position 2.
4. Rotate to adjust time.
5. Push back in to set.

3 EYE CHRONOGRAPH

(Chrono, Raptor, Powerlane, Getaway, Element Chrono, Blacktop II)



SETTING TIME/DATE

1. Pull out Crown until it clicks into Position 1.
2. Rotate clockwise to adjust date.
3. Pull out Crown from Position 1 until it clicks into Position 2.
4. Rotate to adjust time.
5. Push back in to set.


USE CHRONOGRAPH FEATURE

1. Press Pusher A to Start/Stop Stopwatch. Press again to Restart.
2. Press Pusher B to Reset Chronograph.

(To set Chronograph to zero, pull out Crown to Position 2. Press Pusher B until the Stopwatch second hand is back at zero.)

2 EYE CHRONOGRAPH

(Havoc)



SET YOUR DATE/TIME


1. Pull out Crown until it clicks into Position 1.
2. Rotate clockwise to adjust date.
3. Pull out Crown from Position 1 until it clicks into Position 2.
4. Rotate to adjust time.
5. Push back in to set.

USE CHRONOGRAPH FEATURE

1. Press Pusher A to Start/Stop Stopwatch. Press again to Restart.
2. Press Pusher B to reset Chronograph.

2 EYE CHRONOGRAPH

(Blacktop. For Blacktop II setup go to 3 Eye Chronograph)



SET YOUR DATE/TIME

1. Pull out Crown until it clicks into Position 1.
2. Rotate clockwise to adjust date.
3. Pull out Crown from Position 1 until it clicks into Position 2.
4. Rotate to adjust time.
5. Push back in to set.


USE CHRONOGRAPH FEATURE

1. Press Pusher A to Start/Stop Stopwatch. Press again to Restart.
2. Press Pusher B to Reset Chronograph.

(To set Chronograph to zero, pull out Crown to Position 2. Press Pusher B until the Stopwatch second hand is back at zero.)

3 EYE MULTIFUNCTION

(Nova, Duet)




SET YOUR DATE/TIME/DAY

1. Pull out Crown until it clicks into Position 1.
2. Rotate clockwise to adjust date.
3. Pull out Crown from Position 1 until it clicks into Position 2.
4. Rotate to adjust time and day of the week.
5. Push back in to set.

Setting the Dual Time (Second Time Zone)

1. Press Pusher A to advance Second Time Zone hand by 15 minute increments.
2. Press Pusher B to reverse Second Time Zone hand by 15 minute increments.

3 EYE MULTIFUNCTION (Legacy Traveler)




SET YOUR TIME

1. Pull out Crown until it clicks into Position 1.
2. Rotate to adjust time.
3. Push back in to set.

Setting the Dual Time (Second Time Zone)

1. Press Pusher A to advance Second Time Zone hand by 1 hour increments.
2. Press Pusher B to reverse Second Time Zone hand by 1 hour increments.

3 EYE MULTIFUNCTION (Reina)




SETTING TIME/DATE/DAY

1. Pull out Crown until it clicks into Position 1.
2. Rotate to adjust date of month.
3. Pull out Crown from Position 1 until it clicks into Position 2.
4. Rotate to adjust time and day of week.
5. Push back in to set.

(Every 24 hour advancement of time will also advance the day / date.)

3 EYE MULTIFUNCTION (Airhawk)




SET YOUR TIME

1. Pull out Crown until it clicks into Position 1.
2. Rotate to adjust time.
3. Push back in to set.

SET YOUR DAY/DATE

1. Press Pusher A to advance to next day of the week.
2. Press Pusher B to advance to next day of the week.

2 EYE DUAL TIME (Voyager)




SET YOUR DATE/TIME

1. Pull out Crown until it clicks into Position 1.
2. Rotate clockwise to adjust date.
3. Pull out Crown from Position 1 until it clicks into Position 2.
4. Rotate to adjust time.
5. Push back in to set.

SET YOUR SECOND TIME ZONE (DUAL TIME FEATURE)

1. Press Pusher A to advance Second Time Zone hand by 15 minute increments.
2. Press Pusher B to reverse Second Time Zone hand by 15 minute increments.

2 EYE MULTIFUNCTION (Blacktop 8 Year)



SET YOUR TIME


1. Pull out Crown until it clicks into Position 1.
2. Rotate to adjust time.
3. Push back in to set.

SET YOUR DAY/DATE

1. Press Pusher A to advance to next day of the week.
2. Press Pusher B to advance to next day of the week.

SOLAR MOVEMENTS

3 EYE SOLAR CHRONOGRAPH (Blacktop Solar)



SET YOUR DATE/TIME

1. Pull out Crown until it clicks into Position 1.
2. Rotate clockwise to adjust date.
3. Pull out Crown from Position 1 until it clicks into Position 2.
4. Rotate to adjust time.
5. Push back in to set.

CHECK BATTERY LEVEL

1. Press and hold Pusher B for more than 1 second.
2. Stopwatch second hand will move to indicate power level.


USE CHRONOGRAPH FEATURE

1. Press Pusher A to Start/Stop Stopwatch. Press again to Restart.
2. Press Pusher B to Reset Chronograph.

(To set Chronograph to zero, pull out Crown to Position 2. Press Pusher B until the Stopwatch second hand is back at zero.)

AUTOMATIC MOVEMENTS

3 HAND DAY/DATE (Field Automatic)




SET YOUR TIME

1. Pull out Crown until it clicks into Position 2.
2. Rotate to adjust time.
3. Push back in to set.

SET YOUR DAY/ DATE

- Important! If the time of the watch is between 9 p.m. and 4 a.m., don't set the day/date.
1. Pull out Crown until it clicks into Position 1.
 2. Rotate clockwise to adjust date of the month.
 3. Rotate counterclockwise to adjust day of the week.
 4. Push back in to set.


3 HAND (Raptor Automatic)



SET YOUR TIME

1. Pull out Crown until it clicks into Position 1.
2. Rotate to adjust time.
3. Push back in to set.

3 HAND W/ DATE (Sport Minimal Automatic)



SET YOUR DATE/TIME

- Important! If the time of the watch is between 9 p.m. and 4 a.m., don't set the day/date.
1. Pull out Crown until it clicks into Position 1.
 2. Rotate clockwise to adjust date.
 3. Pull out Crown from Position 1 until it clicks into Position 2.
 4. Rotate to adjust time.
 5. Push back in to set.

BEST PRACTICES

WEAR EVERYDAY TO KEEP ACCURATE TIME.

FULLY WIND BEFORE EVERY WEAR.

KEEP IN WATCH WINDER WHEN NOT WEARING.

AVOID MAGNETS, SHOCKS AND WATER EXPOSURE. IF WATER PENETRATES YOUR CASE, TAKE IT FOR REPAIR RIGHT AWAY.

AVOID EXTREME TEMPERATURES. TIMEKEEPING ACCURACY IS AFFECTED BELOW -10°C AND ABOVE 60°C.

SERVICE ABOUT EVERY 3 YEARS TO KEEP UP ITS LONG TERM, QUALITY PERFORMANCE.

SERVICE IN THE RARE EVENT OF TIME-DELAY OR OTHER UNUSUAL OCCURRENCES.

